



INSTALLATION, OPERATION & MAINTENANCE MANUAL OF

BW-INV-SPH3.6K, BW-INV-SPH5K, BW-INV-SPB5K
BW-INV-SPH6K, BW-INV-SPH8K
BW-BAT-4.8S, BW-BAT-9.6P

V0

| DISCLAIMER

Copyright © Bytewatt Technology Co., Ltd. 2024. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Bytewatt Technology Co., Ltd.

The material furnished in this document is believed to be accurate and reliable. The information and recommendations in this document do not constitute commitments or warranties in the form of assignments. The information in this document is subject to change without notice. You may refer to the NEOVOLT Cloud Platform (<https://monitor.byte-watt.com>) for the most updated version.

All company and brand products and service names are trademarks or registered trademarks of their respective holders.

| COPYRIGHT STATEMENT

This manual is under the copyright of Bytewatt Technology Co., Ltd. with all rights reserved. Please keep the manual properly and operate in strict accordance with all safety and operating instructions in this manual. Please do not operate the product before reading through the manual.

TABLE OF CONTENTS

01	INTRODUCTION	01
	1.1 Content and structure of this document	01
	1.2 Target group	01
	1.3 Levels of warning messages	01
	1.4 Definition of abbreviations and nouns	01
02	SAFETY	02
	2.1 Intended use	02
	2.2 Safety instructions for battery	02
	2.2.1 General safety precautions	02
	2.2.2 Response to emergency situations	02
	2.3 Important safety Instructions	03
	2.4 Symbols explanation	04
03	PRODUCT INTRODUCTION AND APPLICATION SCENARIOS	06
	3.1 Nomenclature introduction	06
	3.2 System introduction	06
	3.3 Product description	06
	3.3.1 Inverter electrical interface introduction	06
	3.3.2 Inverter display interface introduction	07
	3.3.2.1 Main interface of the inverter LCD	07
	3.3.2.2 Display content of sub-menu status item	08
	3.3.2.3 Display content of sub-menu history item	08
	3.3.2.4 Display content of general setting item	10
	3.3.2.5 Overloaded state	11
	3.3.3 Battery introduction	12
	3.4 Application scenarios	13
04	STORAGE AND TRANSPORT	14
	4.1 Storage	14
	4.1.1 Inverter storage	14
	4.1.2 Battery storage	15
	4.2 Transport	15
05	MOUNTING	15
	5.1 Checking the outer packing	15
	5.2 Scope of delivery	16
	5.2.1 Scope of delivery for inverter installation	16
	5.2.2 Scope of delivery for wall bracket installation(optional)	16
	5.2.3 Scope of delivery for battery BW-BAT-9.6P installation	17
	5.2.4 Scope of delivery for battery BW-BAT-4.8S installation	18
	5.2.5 Accessories for BAT-9.6P or BAT-4.8S base unit (optional)	18

5.3 Requirements for mounting	19
5.3.1 Basic requirements	19
5.3.2 Mounting environment requirements	19
5.3.3 Mounting structure requirements	19
5.3.4 Mounting angle and stack requirement	19
5.3.5 Mounting space requirements	20
5.4 Preparing tools and instruments	20
5.5 Mounting the product	21
5.5.1 Mounting the battery	21
5.5.1.1. Mounting the battery BW-BAT-9.6P	21
5.5.1.2. Mounting the battery BW-BAT-4.8S	22
5.5.2 Mounting the inverter	27

06 ELECTRICAL CONNECTION 27

6.1 Cable requirements for connection	28
6.2 Connecting additional grounding	28
6.3 AC connection	29
6.3.1 Requirements for the AC connection	29
6.3.2 Grid and backup connection	30
6.3.3 Electricity meter connection	31
6.3.4 Meter connection	31
6.3.5 Configuring the chint meter	34
6.4 PV connection	35
6.5 Electrical connection between the inverter and battery packs	35
6.5.1 Electrical connection between the inverter and battery (BW-BAT-4.8S)	35
6.5.2 Electrical connection between the inverter and battery (BW-BAT-9.6P)	36
6.5.3 AUX/LAN/PV-CT/DRM、RRCR/GRID-CT、Meter/RS485/BMS connection	37

07 INSTALLER ACCOUNT REGISTER AND INSTALL NEW SYSTEM 39

7.1 Register on app	39
7.1.1 Download and install app	39
7.1.2 Register as installer account	39
7.1.3 Overview of functions for installer account	40
7.1.4 Install new system	41
7.2. Register on cloud	43
7.2.1 Register as installer account	43
7.2.2 Install new system	43

08 POWERING ON AND OFF THE SYSTEM 44

8.1 Powering on the system	44
8.2 Powering off the system	44

09	COMMISSIONING	45
	9.1 Checking before power-on	45
	9.2 Mounting the covers of the Inverter	45
	9.2.1 Mounting the top cover	45
	9.2.2 Mounting the side plate (installed on the battery)	46
	9.2.3 Mounting the side plate (wall bracket installation)	46
	9.3 Mounting the Wi-Fi module	47
10	MAINTENANCE AND TROUBLESHOOTING	47
	10.1 Routine maintenance	47
	10.2 Troubleshooting	48
	10.2.1 Inverter error troubleshooting	48
	10.2.2 Battery protection troubleshooting	51
	10.2.3 Battery error troubleshooting	51
11	UNINSTALLATION & RETURN	52
	11.1 Removing the product	52
	11.2 Packing the product	52
	11.3 Disposing of the product	52
12	SPECIFICATION	53
	12.1 Datasheet of inverter	53
	12.2 Datasheet of battery	56
13	CONTACT US	61

1.1. Content and structure of this document

This document is valid for:

Inverter: BW-INV-SPH3.6K, BW-INV-SPH5K, BW-INV-SPB5K, BW-INV-SPH6K, BW-INV-SPH8K

Battery: BW-BAT-4.8S, BW-BAT-9.6P

This document describes the mounting, installation, commissioning, configuration, operation of the product as well as the operation of the product user interface.

Read this document through, understand the safety information, and get familiar with the functions and features of the device before installing and operating it.

Illustrations in this document are reduced to the essential information and may deviate from the real product.

1.2. Target group

This document is intended for qualified persons and end users. Only qualified persons are allowed to perform the operations marked with a warning symbol in this document. Tasks that do not require any specific qualifications will not be marked and can be performed by the end user. Qualified persons must have.

- Knowledge of working principle of inverters.
- Knowledge of how to deal with the dangers and risks associated with installing and using electrical devices, batteries and systems.
- Knowledge of the installation and commissioning of electrical devices and systems.
- Knowledge of the applicable standards and directives.
- Understood and complied with this document, including all safety precautions.
- Understood and complied with the documents of the battery manufacturer, including all safety precautions.

1.3. Levels of warning messages

The following levels of warning messages may occur when handling the product

Symbol	Description
 DANGER	DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	NOTICE indicates a situation which, if not avoided, can result in property damage.
INFORMATION provides tips which are valuable for the optimal installation and operation of the product.	

1.4. Definition of abbreviations and nouns

AC	alternating current	AUX	auxiliary
APP	application	EMS	energy management system

BAT	battery	INV	inverter
BMS	battery management system	MPPT	maximum power point tracking
DC	direct current	PV	photovoltaic

02 SAFETY

2.1. Intended use

The inverter, battery packs and the electricity meters make up a system for optimization of self-consumption for a household. The inverter can achieve bidirectional transfer between AC current and DC current. The battery pack is used for the energy storage.

This system is suitable for indoor and outdoor installation.

Inverter must only be operated with PV arrays of protection class II in accordance with IEC 61730, application class A. The PV modules must be compatible with this product.

PV modules with a high capacity to ground must only be used if their coupling capacity does not exceed 1.0 μF .

All components must operate in a scenario suitable for their operation.

Be sure to use this product in accordance with the information provided in the accompanying documents and local applicable standards and directives. Any other operation may cause personal injury or property damage.

Alterations to the product, e.g. changes or modifications, are only permitted with the express written permission of Bytewatt. Unauthorized alterations will void guarantee and warranty claims.

Bytewatt shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as appropriate.

The enclosed documentation is an integral part of this product. Keep the documentation in a convenient place for future reference and comply with all instructions contained therein.

The type label must remain permanently attached to the product.

2.2. Safety instructions for battery

2.2.1. General safety precautions

- Over voltage or wrong wiring can damage the battery pack and cause deflagration, which can be extremely dangerous.
- All types of breakdown of the battery may lead to a leakage of electrolyte or flammable gas.
- Battery pack is not user-serviceable. There is high voltage in the device.
- Read the label with Warning Symbols and Precautions, which is on the right side of the battery pack.
- Do not connect any AC conductors or PV conductors directly to the battery pack which should be only connected to the inverter.
- Do not charge or discharge damaged battery.
- Do not damage the battery pack in such ways as dropping, deforming, impacting, cutting or penetrating with a sharp object. It may cause a leakage of electrolyte or fire.
- Do not expose battery to open flame.

2.2.2. Response to emergency situations

The battery pack is composed of multiple batteries and designed to prevent the danger caused by malfunction.

If the user touches the inner material of the battery cells due to damage to the shell, the following actions are recommended.

- 1. Inhalation: Leave the contaminated area immediately and seek medical attention.
 - 2. Eye injuries: Rinse eyes with running water for 15 minutes and seek medical attention.
 - 3. Skin injuries: Wash the contacted area with soap thoroughly and seek medical attention.
 - 4. Ingestion: Induce vomiting and seek medical attention.
- If a fire breaks out in the place where the battery pack is installed, perform the following counter-measures:
- **Fire extinguishing media**
 - 1. Respirator is not required during normal operations.
 - 2. Use FM-200 or CO₂ extinguisher for battery fire.
 - 3. Use an ABC fire extinguisher, if the fire is not from battery and not spread to it yet.
 - **Firefighting instructions**
 - 1. If fire occurs when charging batteries, if it is safe to do so, disconnect the battery pack circuit breaker to shut off the power to charge.
 - 2. If the battery pack is not on fire yet, extinguish the fire before the battery pack catches fire.
 - 3. If the battery pack is on fire, do not try to extinguish but evacuate people immediately.

 **WARNING**

There may be a possible explosion when batteries are heated above 150°C. When the battery pack is burning, it leaks poisonous gases. Do not approach.

- **Effective ways to deal with accidents**
 - 1. On land: Place damaged battery into a segregated place and call local fire department or service engineer.
 - 2. In water: Stay out of the water and don't touch anything if any part of the battery, inverter, or wiring is submerged.
 - 3. Do not use submerged battery again and contact the service engineer.

2.3. Important safety instructions

 **DANGER**

Danger to life due to electric shock when live components or cables are touched.

There is high voltage in the conductive components or cables of the product. Touching live parts and cables can result in death or lethal injuries due to electric shock.

- Do not touch non-insulated parts or cables.
- Disconnect the product from voltage sources and make sure it cannot be reconnected before working on the inverter or the battery pack.
- After disconnection, wait for 5 minutes until the capacitors have discharged.
- Do not open the product.
- Wear suitable personal protective equipment for all operations on the product.

 **DANGER**

Danger to life due to danger voltages on the battery pack.

There is danger voltage at the pin connector for the power cable. Reaching into the pin connector for the power cable can result in lethal electric shock.

- Do not open the battery pack.
- Do not wipe over the battery pack with a damp cloth.
- Leave the protective caps on the pin connectors for the batteries power connection until the inverter cables are connected to the battery pack.
- Disconnect the system from voltage sources and make sure it cannot be reconnected before working on the inverter or the battery pack.

 **WARNING**

Risk of chemical burns from electrolyte or toxic gases.

During normal operation, no electrolyte would leak from the battery pack and no toxic gases would form. Despite careful construction, if the battery pack is damaged or a fault occurs, it is possible that electrolyte may be leaked or toxic gases may form.

- Store the battery pack in a cool and dry place.
- Do not drop the battery pack or damage it with sharp objects.
- Only set the battery pack down on its back or its bottom.

- Do not open the battery pack. - Do not install or operate the battery pack in potentially explosive atmosphere or areas of high humidity. - If moisture has penetrated the battery pack (e.g. due to a damaged housing), do not install or operate the battery pack. - In case of contact with electrolyte, rinse the affected areas immediately with water and consult a doctor without delay.	
⚠ CAUTION	Risk of burns due to hot heatsink and housing.
The heatsink and housing can get hot during operation. During operation, do not touch any parts other than the cover of the inverter.	
NOTICE	Damage to the inverter due to electrostatic discharge.
- Touching electronic components can cause damage to or destroy the inverter through electrostatic discharge. - Ground yourself before touching any component.	
NOTICE	Damage due to cleaning agents.
- The use of cleaning agents may cause damage to the product and its components. - Clean the product and all its components only with a cloth moistened with clear water.	
⚠ DANGER	Danger to life due to electric shock when live components or PV cables are touched.
When PV panels exposed to sunlight, the PV array generates high DC voltage which presents in the DC conductors. Touching the live DC cables can result in death or lethal injuries due to electric shock. - Disconnect the inverter from voltage sources and make sure it cannot be reconnected before working on the device. - Do not touch non-insulated parts or cables. - Do not disconnect the DC connectors under load. - Wear suitable personal protective equipment for all work on the inverter.	
⚠ DANGER	Danger to life due to electric shock from touching an ungrounded PV module or array frame.
- Touching ungrounded PV modules or array frames can result in death or lethal injuries due to electric shock. - Connect and ground the frame of the PV modules, the array frame and the electrically conductive surfaces so that there is continuous conduction. - Observe the applicable local regulations.	
⚠ DANGER	Danger to life due to electric shock when touching live system components in case of a ground fault.
When a ground fault occurs, parts of the system may still be live. Touching live parts and cables can result in death or lethal injuries due to electric shock. - Disconnect the product from voltage sources and make sure it cannot be reconnected before working on the device. - Touch the cables of the PV array on the insulation only. - Do not touch any parts of the substructure or frame of the PV array. - Do not connect PV strings with ground faults to the inverter.	

2.4. Symbols explanation

Symbol	Explanation
	Beware of a danger zone This symbol indicates that the product must be additionally grounded if additional grounding or equipotential bonding is required at the installation site.
	Beware of electrical voltage The product operates at high voltages.



Beware of hot surface
The product can get hot during operation.



Danger to life due to high voltages in the inverter, observe a waiting time of 5 minutes.
Prior to performing any work on the inverter, dis-connect it from all voltage sources as described in this document.



WEEE designation
Do not dispose of the product together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.



Observe the documentation.



CE marking
The product complies with the requirements of the applicable EU directives.



RCM (Regulatory Compliance Mark)
The product complies with the requirements of the applicable Australian standards.



UKCA marking
The product complies with the regulations of the applicable laws of England, Wales and Scotland.



RoHS labeling
The product complies with the requirements of the applicable EU directives.



Risk of chemical burns.



Risk of explosion.



Risk of electrolyte leakage.



Refer to the instruction for operation.



Use eye protection.



Fire, naked light and smoking prohibited.



No nearing.



Do not dispose of the battery pack together with the household waste but in accordance with the locally applicable disposal regulations for batteries.



Recycling code.

UN38.3


Marking for transport of dangerous goods
The product passes the certifications of the UN38.3.

03 PRODUCT INTRODUCTION AND APPLICATION SCENARIOS

3.1. Nomenclature introduction

Name	Designation in this document
BW-INV-SPH3.6K BW-INV-SPH5K BW-INV-SPB5K BW-INV-SPH6K BW-INV-SPH8K	3.6kW Single-phase hybrid inverter 5kW Single-phase hybrid inverter 5kW Single-phase battery inverter 6kW Single-phase hybrid inverter 8kW Single-phase hybrid inverter
BW-BAT-4.8S BW-BAT-9.6P	Battery

3.2. System introduction



BW-BAT-9.6P

Dimension(W×H×D): 590×1136×206mm

BW-BAT-4.8S


Dimension(W×H×D):
590×406+430*N×206mm

N: Number of batteries

Object	Name	Explain
1	BW-INV-SPH3.6K BW-INV-SPH5K BW-INV-SPB5K BW-INV-SPH6K BW-INV-SPH8K	Inverter
2	BW-BAT-9.6P BW-BAT-4.8S	Battery

3.3. Product description

3.3.1. Inverter electrical interface introduction



Position	Designation
1	Grid Connector
2	Backup Connector
3	Battery+ Power Connector
4	Battery- Power Connector
5	Battery Circuit Breaker* of the Inverter
6	Positive and Negative PV connectors, PV1/ PV2
7	PV Switch
8	Wi-Fi Port
9	Communication Ports (CAN/RS485,BMS, LAN, Meter/Grid-CT, DRM**, PV-CT, AUX)
10	Inverter LCD
11	Grounding

*All breakers of the product are switched off when shipped.
 **The DRM is only for regions with AS/NZS 4777.2 grid regulations.

3.3.2. Inverter display interface introduction

LCD Display

Object	Name	Description
A	SYS LED	Red: The inverter is in fault.
		White: The inverter is in normal state.
	BAT LED	White: The battery is in charging or discharging.
	COM LED	White: The inverter is in communication.
B	LCD Display	Display the information of the energy storage system.
C	Button Function	Escape from current interface or function.
		Move cursor to upside or increase value.
		Move cursor to downside or decrease value.
		Confirm the selection.

3.3.2.1 Main interface of the inverter LCD

Power0W Total00.0kWh Battery% Normal	Main displays the inverter working status and information,including: 1.Power: Current PV power. 2.Total: Total power generation. 3.Battery: Current remaining battery power (SOC). 4.Normal: Current working state of the equipment, including Standby.
>>>>MENU<<<< >Status History Setting	In the Main interface, press ENT key to enter the menu's main interface. Use the up and down key to select a sub-menu, press the ENT key to enter the selected sub-menu, press Return key to return to the previous layer.

3.3.2.2 Display content of sub-menu status item

>>>> Status <<<< >Grid Soalr Battery	Status menu contains five sub-menus: Solar, Battery, Grid, UPS and Comm. These display the relevant information about the current physical or communication interface respectively.
>>>> Grid <<<< >U 230.2V I 2.0A F 49.99Hz	Grid interface displays the real-time information on the utility grid side: voltage U, current I, frequency F, PInv, PMeter AC, PMeter DC.
>>>> Solar <<<< >U1 360.0V I1 1.0A P1 360W	Solar interface displays the real-time information of PV side: voltage U1, current I1, power P1.
>>>> Battery <<<< >U 96.0V I 10.0A P 960W	Battery interface displays the real-time information of battery side: voltage U, current I, power P, residual capacity of Battery (SOC), the internal environmental temperature Temp.
>>>> UPS <<<< >U 230.2V I 2.0A P 460W	UPS interface displays the real-time information in this mode: voltage U, current I, power P.
>>>> Comm <<<< >BMS Yes Net Yes MeterGrid Yes	Communication interface displays the real-time communication situation of BMS, Net, MeterGrid and MeterDC.

3.3.2.3 Display Content of Sub-Menu History Item

>>>> History <<<< >Grid Consump INV Gen. BAT Gen.	History menu contains seven sub-menus: Grid Consumption, INV Gen., BAT Gen.
---	--

> Grid CONSUMP < > Total: 0.0kWh	Grid Consumption interface displays today's or total load consumption from grid.
>>> INV Gen. <<< >Today: 29.1kWh	INV Gen. interface displays today's or total electricity quantity generated from Inverter.
>>> Bat Gen. <<< >Today: 13.8kWh	Bat Gen. interface displays today's or total electricity quantity discharged from the battery.
>>> PV Gen. <<< >Today: 19.0kWh	PV Gen. interface displays today's or total electricity quantity generated from the PV-panels.
>>> Grid Charge <<< >Today: 1.9kWh	Grid Charge interface displays today's or total electricity quantity battery charging from the grid.
>>> PV Charge << >Today: 13.1kWh	PV Charge interface displays today's or total electricity quantity battery charging from the PV-panels.
>>> Error Logs <<< 1: 2018-02-02 16:48 Chg SPI Fault	Error Logs interface displays the 10 latest fault records of this device, including the name of the fault and time of error.
>> Information < >SN: 2500xxxxxxxxxx	Make sure all numbers in the information menu are correct.


>> Information < >Inverter Ver.:	Check the inverter software version.
---	--------------------------------------

3.3.2.4 Display content of general setting item

> New Password < > 0 0 0 0	Step1: Click setting and enter the password. The installation's password is a four-digits password: 1111, after four-digits password was correctly input, you can enter into the main Setting interface (administrator permissions).	
>>> Setting <<< >Function Safety Step2: Click Function to enter function setting.	>>> Function <<< >Solar Battery Grid Step3: Click Solar to set the Solar relevant information.	>>> Solar <<< >On Grid Cap. 000000W Step4: Set on-grid capacity, storage capacity and number of PV strings (MPPT number).
>>>> Battery <<<< >Bat Model BW-BAT-XXX Step5: Click the Battery Function and check battery type.	>>>> Battery <<<< >SOC Calibration No Step6: Check SOC Calibration function set No.	>>>> Battery <<<< >Battery Ready No Step7: Check the Battery Ready function set No. If you only use the inverter without battery, please set it Yes.
>>>> Grid <<<< >FeedIN Control Power Limit Power Factor Step8: Click the Grid Function to set up relevant parameters of the grid.	Max. Feed in rate >User Value 50% Step9: Set the Max. Feed in rate value.	>> System Mode << >DC AC Hybrid Step10: Click Function-System Mode to set system mode: DC, AC, Hybrid.
>>> Work Mode << >Force Charge Enable Step11: Click the mode then set up work mode.(self-use or force time charge)	>>> Work Mode << >Force Charge Enable Step12: If you want to use force charge, sett Enable here.	>>> Work Mode << > Charge Start Time 1 01:00 Step13: Set the charge and discharge time.


>>> Work Mode <<< >UPS Reserve SOC 11% Step14: Set the UPS Reserve SOC, it means how much battery energy to reserve for UPS function.	>>>> Safety <<<< > Country AS4777 Step15: Click Safety in the setting menu. Set safety standard.For example: AS4777 for Australia, VDE4105 for Germany, CEIO_21 for Italy, G83_2 for Great Britain, NRS097_2_1 for South Africa, RD1699 for Spain, VDE0216 for 60Hz countries.	
>>> CT Meter <<< >Enable OFF Ratio 1 Step16: If you use CT meter, please set CT meter enable and the relevant ratio.	>> UPS System << >Mute YES Frequency: 50Hz Step17: If you use UPS function, please set the mute as YES in UPS System interface and the relevant Frequency.	>> Date&Time << > 2018-02-02 09:46 Step18: Click System in the setting menu. Click Date &Time and set up the date and time.
>>> Ethernet <<< IP method > DHCP Step19: Click Ethernet to set the IP address. DHCP mode means that setup IP address is set up automatically. If you want to set up the IP address manually, please choose manual mode.		
Note: It is needed to set the following 3 parameters for manual mode: IP Address: IP address; Subnet Mask: Subnet mask; Default Gateway: Default gateway; Automatic display one parameter: MAC Address: display MAC Address.		
>>>> Language <<<< > English Deutsch Italian Step20: Click Language to set Language Date & Time Setting Interface.	>>> Information <<< >SN: 2500xxxxxxxxxx Step21: Make sure all the following number is correct. Date & Time Setting Interface.	

3.3.2.5 Overloaded state




3.3.3. Battery introduction

Battery pack appearance and dimensions




Connection area overview of BW-BAT-9.6P



Position	Designation
1	Battery Positive Power Connector
2	Battery Negative Power Connector
3	Grounding
4	BMS COM 1
5	BMS COM 2 (with terminal resistance)
6	Battery LED Display
7	Battery Power Button
8	Battery Breaker

Connection area overview of BW-BAT-4.8S



Position	Designation
1	BMS COM 1
2	Battery Positive Power Connector
3	Grounding
4	Battery Circuit Breaker
5	BMS COM 2 (with terminal resistance)
6	Battery Negative Power Connector
7	Battery LED Display



During normal operation of battery, three LED indicators on the front cover provide information about the SOC of the battery with white lights on and off or flashing (0.5S on, 1.5S off) .

- ☼ : White LEDs are flashing
- ⦿ : White LEDs are glowing
- : White LEDs are off


LED Indicator	No.	SOC	Description
LEDs show the SOC status	1	☼ ○ ○	$SOC \leq 10\%$
	2	⦿ ○ ○	$10\% < SOC \leq 30\%$
	3	☼ ☼ ○	$30\% < SOC \leq 50\%$
	4	☼ ☼ ○	$50\% < SOC \leq 60\%$
	5	☼ ☼ ☼	$60\% < SOC \leq 90\%$
	6	☼ ☼ ☼	$90\% < SOC \leq 100\%$

3.4. Application scenarios


Storage System (includes inverter BW-INV-SPH3.6K/BW-INV-SPH5K/BW-INV-SPB5K/BW-INV-SPH6K/BW-INV-SPH8K and battery BW-BAT-9.6P/BW-BAT-4.8S) can be applied in DC-coupled systems (mostly new installation), AC-coupled systems (mostly retrofit), Hybrid-coupled systems (mostly retrofit, and increase the PV capacity), and Off-grid (with Generator) systems as the following schemes show:




Hybrid-coupled storage system



Off grid storage system



Off grid storage system with dual power switch box



04 STORAGE AND TRANSPORT

4.1. Storage

4.1.1. Inverter storage

The following requirements should be met if the inverter is not put into use directly:

1. Do not unpack the inverter.
2. Keep the storage temperature at -40-60°C and the humidity at 5%-95% RH.

3. The inverter should be stored in a clean and dry place and be protected from dust and water vapor corrosion.
4. A maximum of six inverters can be stacked. To avoid personal injury or device damage, stack inverters with caution to prevent them from falling over.
5. During the storage period, check the inverter periodically. Replace the packing materials which are damaged by insects or rodents in a timely manner.
6. If the inverters have been stored for more than two years, it must be checked and tested by professionals before being put into use.

4.1.2. Battery storage

The following requirements should be met if the battery is not put into use directly:

1. Place batteries according to the signs on the packing case during storage. Do not put batteries upside down or sidelong.
2. Stack battery packing cases by complying with the stacking requirements on the external package.
3. Store the battery pack out of reach of children and animals.
4. Store the battery pack where it should be minimal dust and dirt in the area.
5. Handle batteries with caution to avoid damage.
6. The storage environment requirements are as follows:
 - a. Ambient temperature: -10-55°C, recommended storage temperature: 15-30°C.
 - b. Relative humidity: 15%- 85%.
 - c. Place batteries in a dry and clean place with proper ventilation.
 - d. Place batteries in a place that is away from corrosive organic solvents and gases.
 - e. Keep batteries away from direct sunlight.
 - f. Keep batteries at least 2m away from heat sources.
7. The batteries in storage must be disconnected from external devices. The indicators (if any) on the batteries should be off.
8. Batteries should be delivered based on the "first in, first out" rule.
9. The warehouse keeper should collect battery storage information every month and periodically report the battery inventory information to the planning department. The batteries that have been stored for nearly 6 months should be recharged timely.
10. If a lithium battery is stored for a long time, capacity loss may occur. After a lithium battery is stored for 12 months in the recommended storage temperature, the irreversible capacity loss rate is 3%-10%. It is recommended that batteries not be stored for a long period. If the batteries need to be stored for more than 6 months, it is recommended to recharge the batteries to 65-75% of the SOC.

4.2. Transport

During transportation, please follow these guidelines:

1. Priority to use the original packaging for transportation. If the original packaging is not available, put the product inside a suitable cardboard box and seal it properly.
2. Handle with care, choose the corresponding handling method according to the weight, and pay attention to safety.
3. During transportation, please keep the packaging away from dangerous sources and take water-proof measures.
4. Please fix the packaging during transportation to prevent falling or mechanical impact.



05 MOUNTING




















5.1. Checking the outer packing

Before unpacking the product, check the outer packing for damage, such as holes and cracks. If any damage is found, do not unpack the product and contact your dealer as soon as possible.




5.2. Scope of delivery















Check the scope of delivery for completeness and any externally visible damage. Contact your distributor if the scope of delivery is incomplete or damaged.

5.2.1. Scope of delivery for inverter installation

				
Inverter (X1)	TOP Cover (X1)	Left Cover (X1)	Cable Cover (X1)	Left Support Foot (X1)
				
Right Support Foot (X1)	PV Connectors (x2)	Grid Connector(X1)	Backup Connector (X1)a	Backup Connector (X1)b
				
Screws and Terminals Set (x1)	WiFi Module (x1)	6 Pin AUX Terminal Block (X1)	Grid-CT(x1) Grid-CT line (x1)c	PV-CT(x1) PV-CT line (x1)c
				
Wrench Tool (X1)	Negative Power Cable (x1)d	Positive Power Cable (x1)d	Negative Power Cable (x1)e	Positive Power Cable (x1)e
		a: Use for INV-6K/8K b: Use for INV-3.6k/5K c: Optional d: Use for BAT-4.8S e: Use for BAT-9.6P		
Communication Cable (x1)e	Documentation (x1)			







5.2.2. Scope of delivery for inverter wall bracket installation (Optional)


				
Inverter (X1)	TOP Cover (X1)	Left Cover (X1)	Right Cover (x1)	Horizontal Beams of Wall Bracket (x1)

				
Support Plate for Cable Cover (x1)	Support Stud for Right Cover (x1)	ST6*55 (x5)	Small Spirit Level (x1)	PV Connectors (x2)
				
Grid Connector (x1)	Backup Connector (x1)a	Backup Connector (x1)b	6 Pin AUX Terminal Block(x1)	WiFi Module (x1)
				
Grid-CT(x1) Grid-CT line (x1)c	PV-CT(x1) PV-CT line (x1)c	Wrench tool(x1)	Negative Power Cable (x1)d	Positive Power Cable (x1)d
				
Negative Power Cable (x1)e	Positive Power Cable (x1)e	Communication Cable (x1)e	Documentation (x1)	

a: Use for INV-6K/8K
b: Use for INV-3.6k/5K
c: Optional
d: Use for BAT-4.8S
e: Use for BAT-9.6P










5.2.3. Scope of delivery for battery BAT-9.6P installation

Battery				
				
Battery Pack (X1)	Wall Anchor ST6*55 (X4)	Spanner (X1)	Left Cable Cover (X1)	Y Type Terminal (X2)
				
Wall Bracket (X1)	BAT+ Cable (X1)	BAT- Cable (X1)	Network Cable (X1)	Countersunk Screw (X6)







Quick
Installation
Guide (X1)

5.2.4. Scope of delivery for battery BAT-4.8S installation

Battery				
				
Battery (X1)	Left Cable Cover (X1)	Wall Bracket (X1)	Connecting Plate for Wall Brackets (X2)	Right Holder for Wall Bracket (X1)
				
Left Holder for Wall Bracket (X1)	Wall Anchor St6*55 (X6)	Grounding Cable (X1)	Small Gasket Screw M5×12* (X5)	Large Gasket Screw M5×12 (X3)
			* Use for mounting right holder for wall bracket and left holder for wall bracket	
Flange Nut M5 (X6)	Quick Installation Guide (X1)	Y Type Terminal (X1)		

5.2.5. Accessories for BAT-9.6P or BAT-4.8S base unit (optional)

				
Base Unit (X1)	Bracket for Base (X1)	Bracket for Top Battery (X1)	Wall Anchor St6*55 (X4)	Small Gasket Screw M5×12(a) (X11)
			(a): Use for mounting wall bracket for base and top battery.	
Large Gasket Screw M5×12 (X17)	Connection Sheet for Wall Holders (X4)	Wrench SW16 (X1)		

5.3. Requirements for mounting

⚠ WARNING

Danger to life due to fire or explosion

Despite careful construction, electrical devices can cause fires.

- Do not mount the energy storage system in areas containing highly flammable materials or gases.
- Do not mount the energy storage system in potentially explosive atmospheres.

5.3.1. Basic requirements

- The LSHE Inverter and Battery system is suitable for indoor and outdoor use.
- Do not install the inverter in a place where a person can easily touch it because its housing and heatsink are hot during operation.
- Do not mount the system in areas with flammable or explosive materials.
- Do not mount the inverter at a place within children's reach.
- Do not mount the system outdoors in salt areas because it will be corroded there and may cause fire. A salt area refers to the region within 500m from the coast or prone to sea breeze. The regions prone to sea breeze vary depending on weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).

5.3.2. Mounting environment requirements

- The system must be mounted in a well-ventilated environment to ensure good heat dissipation.
- When mounted under direct sunlight, the power of the system may be derated due to additional temperature rise.
- Mount the system in a sheltered place or mount an awning over the product.
- The optimal temperature range for the battery pack to operate is from 15 °C to 30 °C.
- Do not expose or place near water sources like downspouts or sprinklers.
- If the battery pack is mounted in the garage, then ensure that it is above the height of the vehicle bumper and/ or door.

5.3.3. Mounting structure requirements



- The mounting structure where the system is mounted must be fireproof.
- Do not mount the system on flammable building materials.
- Ensure that the mounting surface is solid enough to bear the weight load.
- In residential areas, do not mount the inverter on dry walls or walls made of similar materials which have a weak sound insulation performance because the noise generated by the inverter is noticeable.

5.3.4. Mounting angle and stack requirement

The system should be mounted on the wall.


The installation angle requirement is as follow:

- Do not mount the inverter at forward tilted, side tilted, horizontal, or upside down positions.






5.3.5. Mounting space requirements

- Reserve sufficient clearance around the product to ensure sufficient space for installation, maintenance and heat dissipation.
- The side clearance is a recommendation. Keep the clearance as short as you can if there is no influence to the operation and maintenance.



5.4. Preparing tools and instruments

Category	Tools and Instruments		
Installation			
	Hammer drill (with a Φ10 mm drill bit)	Torque socket wrench SW10	Multimeter (DC voltage range ≥ 1000 V DC)
			
	Diagonal pliers	Wire stripper	T20 screwdriver (torque range: 0-5 N m) L < 200mm
			
	Rubber mallet	Utility knife	Cable cutter
			
	Crimping tool (model: PV-CZM-22100)	Cord end terminal crimper	Disassembly and Assembly Tool of PV connector
			
	Vacuum cleaner	Heat shrink tubing	Heat gun


Personal Protective Equipment			
	Marker	Measuring tape	Bubble or digital level
			
	Safety gloves	Safety goggles	Anti-dust respirator
			
	Safety shoes	Flat-Head Screwdriver	Socket Wrench

5.5. Mounting the product





5.5.1. Mounting the battery

5.5.1.1. Mounting the battery BW-BAT-9.6P

- a. Take out the battery from the carton, transport it to the installation site with a handcart which bearing capacity should be greater than 200kg, tied with bandage.
- b. Place the battery against the wall, mount the wall panels and then mark drill positions.
- c. Fix the bolt wall bracket on the box with 3pcs M5*10 screws;
- d. Select a set of symmetrical OB holes for tracing points, and remove the product after tracing points are completed ;
- e. Drill 2 holes on the wall with a diameter of 10mm and a depth of about 70mm.
- f. After cleaning the dust and other objects from the two holes, place 2 wall anchors into the holes, then attach the battery wall bracket to the wall by using the SW18 hexagon sleeve. Please use a level to ensure that the wall bracket is horizontal.










(1) Wall bracket installation



(a) This recommended value is for the location which is the middle hole of the wall bracket for the bottom battery.

NOTICE (b) Ensure that the wall bracket is mounted horizontally using a spirit level before securing the wall bracket.





Wall-mounted battery disassembly


CAUTION Risk of injury due to the weight of the battery

Incorrectly lifting or dropping the battery during transportation, mounting, or disassembling may lead to injuries.



- Transport and lift the battery carefully. Take the weight of the product into account.
- Always have two or more people to mount and disassemble the product.
- Wear suitable personal protective equipment for all work on the product.

When disassembling the battery which has been mounted with wall bracket and not directly connected to the inverter, always hold the handles on both sides of the battery firmly and slide it to



the left. Once the contour of the round hole of the upper left handle is close with the left edge of the front cover, carefully lift the battery forward and off the wall bracket.















(2) Base Installation (Optional)



Ensure that the base is mounted horizontally using a spirit level before securing the base fixing bracket.









(a) This recommended value is for the location which is the middle hole of the wall bracket for the bottom battery.


For mounting multiple batteries, please follow as above steps.

If you will install extra batteries by side, please keep the distance between two batteries greater than 300mm. You can install extra batteries up to 6 batteries in a system.



5.5.2. Mounting the inverter

- a.Fit the left and right side brackets onto the top of the battery.
- b.Attach the inverter to the mounting bracket. Mount the supporting bracket at the bottom of the inverter.



06 ELECTRICAL CONNECTION

Precautions

⚠ DANGER	Before connecting cables, ensure that all breakers of the inverter and the battery packs and all the switches connected to inverters and the battery packs are set to OFF. Otherwise, the danger voltage of the energy storage system may result in electric shocks.
⚠ WARNING	• The energy storage system damage caused by incorrect cable connections is not covered under any warranty. • Only certified electricians are allowed to connect cables. Operation personnel must wear proper PPE when connecting cables
NOTICE	The cable colors shown in the electrical connection diagrams provided in this chapter are for reference only. Select cables in accordance with local cable specifications (green-and-yellow cables are only used for PE).

6.1. Cable requirements for connection

No.	Cable	Type	Conductor Cross Section Area Range	Outer Diameter	Source
1	Battery power cable	Standard PV cable in the industry (recommended type: PV1-F)	16 mm ²	N/A	Delivered with the battery
2	Battery communication cable	Standard network cable in the industry (recommended type: Cat5e, UTP, UV-resistant for outdoor use)	0.12-0.2 mm ² (AWG26-AWG24)	N/A	Delivered with the battery
3※1	Signal cable	Standard network cable in the industry (recommended type: Cat5e, FTP, UV-resistant for outdoor use)	0.12-0.2 mm ² (AWG26-AWG24)	N/A	Delivered with the inverter
4	PV Power cable	Standard PV cable in the industry (recommended type: PV1-F)	4-6 mm ²	5.5-9 mm	Purchased by the installer
5※2	Signal cable	Standard network cable in the industry (recommended type: Cat5e, FTP, UV-resistant for outdoor use)	0.12-0.2 mm ² (AWG26-AWG24)	4-6 mm	Purchased by the installer
6※3	Signal cable	Multiple-core outdoor shielded twisted pair cable	0.1-1.3 mm ²	4-6 mm	Purchased by the installer
7	AC power cable for backup	Three-core (L, N and PE) outdoor copper cable	6-10 mm ²	12-18 mm	Purchased by the installer
8	AC power cable for grid	Three-core (L, N and PE) outdoor copper cable	6-10 mm ²	12-18 mm	Purchased by the installer
9	PE cable	Single-core outdoor copper cable	6-10 mm ²	N/A	Purchased by the installer

※1 For CT communication connection with inverter.

※2 For CAN/RS485, LAN, Meter, DRM communication connection with inverter.

※3 For AUX communication connection with inverter.

6.2. Connecting additional grounding

NOTICE

Electric Shock Hazard


Before doing electrical connection, please ensure the PV switch & all AC and BAT circuit breakers in the energy storage system are switched OFF and cannot be reactivated.

External grounding points are provided at the left side of the inverter.


Prepare M5 OT terminals, strip the grounding cable insulation, insert the stripped part of the grounding cable into the ring terminal lug and crimp using a crimping tool.

Connect the OT terminal to grounding point using the torque 2.5 N.m with T20 screwdriver.


Additional grounding connection for inverter.




Grounding connection between inverter and battery.



Battery BW-BAT-9.6P



Battery BW-BAT-4.8S



6.3. AC connection

6.3.1. Requirements for the AC connection

NOTICE	Residual-current monitoring unit: The inverter does not require an external residual-current device when operating. If local regulations require the use of a residual-current device, or Hybrid-coupled storage system with big coupling capacity from the PV array and PV inverter, the following must be observed: The inverter is compatible with type B residual-current devices with a rated residual current of 30mA or less. Each inverter in the system must be connected to the utility grid via a separate residual-current device.
⚠ DANGER	You must protect each inverter with an individual grid/backup circuit breaker in order to ensure that the inverter can be disconnected safely.

Grid connection recommendation for INV-3.6K			
Description	Max. Current	Breaker Type for 3.6K	Recommend cable cross section
Grid Side	32 A	50 A	6 ~ 10 mm ²
Backup Side	16 A	32 A	4 ~ 6 mm ²

Grid connection recommendation for INV-5K			
Description	Max. Current	Breaker Type for 5K	Recommend cable cross section
Grid Side	43.5 A	63 A	10 mm ²
Backup Side	21.7 A	32 A	4 ~ 6 mm ²

Grid connection recommendation for INV-6K			
Description	Max. Current	Breaker Type for 6K	Recommend cable cross section
Grid Side	50 A	63 A	10 mm ²
Backup Side	50 A	63 A	10 mm ²

Grid connection recommendation for INV-8K			
Description	Max. Current	Breaker Type for 8K	Recommend cable cross section
Grid Side	50 A	63 A	10 mm ²
Backup Side	50 A	63 A	10 mm ²


WARNING

Selecting a circuit breaker and copper conductor cross section


For INV-6K/8K, the maximum allowable grid circuit breaker specification is 50A at the same time the copper conductor cross section for grid connection must be 10mm². You should use APP or cloud to do the right setting for example when selecting grid circuit breaker specification 50A and suitable copper conductor cross section, otherwise it increases the danger of the circuit breaker tripping under normal operating conditions.

6.3.2. Grid and backup connection


Connecting grid/backup power cable

The wiring steps are also suitable for backup connection of INV-6K/8K.
 Bush insert of backup connector of the INV-6K/8K is blue.
 Bush insert of AC connector of the INV-6K/8K is black.


Step 1




Step 2




Step 3



Step 4




The wiring steps are only suitable for backup connection of INV-3.6K/5K.



6.3.3. Electricity meter connection

Item	Current	Scenarios
DTSU666-3*230V 5(80)A	80A	Three phase meter (without CT)

Loosen the swivel nuts of the cable glands on the COM connection cover of Inverter, and unscrew the 4 screws on the corners, then you will see the grid CT, PV CT and meter communication ports.




6.3.4. Meter connection

Lead the meter cable through the cable gland of the COM connection cover, don't tighten the swivel nuts of the cable glands.
Insert the RJ45 plugs to the meter communication port.


The other steps for meter DTSU666-3*230V 5(80)A connection as follows:
1.Wiring at single-phase feed in:

Wiring at single-phase feed in (DC)




DC-coupled storage system

Wiring at single-phase feed in (AC)






AC-coupled storage system

Wiring at single-phase feed in (Hybrid)



Hybrid-coupled storage system


2.Wiring at three-phase feed in:




6.3.5. Configuring the chint meter

Model	Grid Meter Address	PV Meter Address
DTSU666-3*230V 5(80)A (without CT)	1	2

When the meter is used as Grid meter, please follow the steps below to complete the address setting.



When the meter is used as PV meter, please follow the steps below to complete the address setting.



Meter Setting on Neovolt Cloud

Step 1:

When the system work mode is selected as DC, click the button under the "Grid Meter" to turn the "Meter" icon green.

When the system work mode is selected as AC or Hybrid, click the buttons under the "Grid Meter" and "PV side meter" to turn the "Meter" icon green.

Step 2:

Click "Save" and wait a few minutes to refresh the page.

When the "Meter Model" displays DTSU666 model, the setting is successful.

NOTICE

It is forbidden to tick CT to modify the CT ratio.

Meter Information

Grid Meter

Meter

CT

CT

Meter CT Ratio

Meter Model

DTSU666-3*230V5A

PV side meter

Meter

CT

CT

Meter CT Ratio

Meter Model

0

Meter Setting on "NEOVOLT" APP


Step 1:

When the system work mode is selected as DC, only tick "Meter" icon on the right of the "Grid Meter".

When the system work mode is selected as AC or Hybrid, both tick "Meter" icon on the right of the "Grid Meter" and "PV side meter".

Step 2:

Click "Submit" and enter the "System information" page to check the meter model. When the "Meter Model" displays DTSU666 model, the setting is successful.



NOTE

It is forbidden to tick CT to modify the CT ratio.


6.4. PV connection

Please ensure the follows before connecting PV strings to the Hybrid inverter:

- Make sure the open voltage of the PV strings will not exceed the max. DC input voltage (580-Vdc). Violating this condition will void the warranty.
- Make sure the polarity of the PV connectors is correct.
- Make sure the PV-switch, breakers of battery, AC-BACKUP and AC-Grid are all in their off-states.
- Make sure the PV resistance to ground is higher than 200k ohm.


The inverter uses the Vaconn D4/MC4(optional) PV connectors. Please follow the picture below to assemble the PV connectors.

PV conductor cross section requirements: 4-6 mm².



6.5. Electrical connection between the inverter and battery packs


6.5.1. Electrical connection between the inverter and battery (BAT-4.8S)



3

Inverter side


Battery side




4

Inverter side

Battery side





6.5.2. Electrical connection between the inverter and the battery (BAT-9.6P)



⚠ DANGER


Danger to life due to short-circuiting of the battery

Touching the short circuit connection of the battery results in death or lethal injuries due to electric shock and massive energy release. Switch off the battery breaker which is located at the top-right of the battery. Please connect both ends of one battery power cable completely before connecting the next power cable to avoid short circuit of the positive and negative battery power cables.




6.5.3. AUX/LAN/PV-CT/DRM、RRCR/GRID-CT、Meter and RS485 connection

For other communication (AUX, DRM, PV-CT, RRCR/Grid-CT, Meter and RS485) connection, please follow the below steps.



1. Loosen the cable glands on the COM connection cover, and then unscrew the 4 screws on the COM connection cover.
2. Lead the communication cables through the cable glands of the COM connection cover, don't tighten the swivel nuts of the cable glands.
Insert the RJ45 plugs to the relative RJ45 sockets.
 - 1) For meter wiring, refer to Chapter 6.3.5 for Meter Connection.
 - 2) If DRM support is specified, the system may only be used in conjunction with a Demand Response Enabling Device (DRED). This ensures that the system implements the commands from the grid operator for active power limitation at all times. The system and the Demand Response Enabling Device (DRED) must be connected in the same network.
Only DRM0 is available for Inverter.
 - 3) Take out 6 pin terminal block for AUX connection. To do wiring connection, insert a screwdriver (blade width: 1.2 mm) into the relative connection position side.
For AUX position definition, please see the AUX wiring documentation.



3. Place the COM connection cover against the inverter housing and tighten the 4 screws, at last secure the swivel nut of the cable glands.
The pin definition of the communication ports:

AUX	1	2	3	4	5	6		
	DO1_N	DO1_COM	DO1_NC	DI_negative	DI_positive	GND		
DRM	1	2	3	4	5	6	7	8
	DRED 1/5	DRED 2/6	DRED 3/7	DRED 4/8	REF GEN/0	COM LOAD/0	/	/
PV_CT	1	2	3	4	5	6	7	8
	PV_CT-	PV_CT+	RS485_A7	NC	NC	RS485_B7	NC	NC
GRID_CT / METER	1	2	3	4	5	6	7	8
	GRID_CT -	GRID_CT +	RS485_A7	NC	NC	RS485_B7	NC	NC
RS485	1	2	3	4	5	6	7	8
	13.5V	DEBUG_RX-D_COM	GND	RS485_B5	RS485_A5	NC	DEBUG_TX-D_COM	NC
BMS	1	2	3	4	5	6	7	8
	NC	RS485_A4	NC	CAN1_H	CAN1_L	NC	RS485_B4	NC

7.1. Register on app

7.1.1. Download and install app

1. Android device users can download the "NEOVOLT" App through major Android application markets such as Google Play.
2. IOS device users can search for "NEOVOLT" in App Store and download the App.


7.1.2. Register as installer account

If you don't have an installer account, please register firstly.

The image displays three screenshots from the NeoVOLT mobile application. The first screenshot, titled 'Register', shows the login and registration options. It includes fields for 'Account' (username) and 'Password', a 'Remember me' checkbox, a 'Forgot password' link, and two role selection buttons: 'End user Registration' and 'Installer Registration'. The 'Register' button is highlighted with a blue box. The second screenshot, titled 'Installer Registration', shows a form for creating an installer account. It includes fields for 'License Number', 'Contact number', 'Contact Person', 'Country', 'Post code', 'Working Region - State (optional)', 'Working Region - City (optional)', 'Address', and 'Time zone'. A callout box points to the 'License Number' field with the text 'Get the license No. from your distributor.' The third screenshot shows the 'OK' button and the 'Register' button, which is again highlighted with a blue box.

If you already have an installer account, please log in directly.

7.1.3. Overview of functions for installer account



7.1.4. Install new system

10:43

88

NEOVOLT

13151100750100

1315

Feedback

Document Center

Install EV-Charger

Install New System

System list

About App

About Neovolt

Switch Theme

Home

Me

After login, click "Install New System"

09:01

91

Install New System

S/N

S/N

Check code

You can find the SN and check code on the label of the inverter. Scan or type in.

License

License

Installation date

2023-03-09

Bind the current SN to an existing end user account?

No

Yes

User name

User name

Remark(optional)

Fill in the issue

11:54

90

Install New System

S/N

S/N

Check code

Check code

License

License

Street(NMI)

Street(NMI)

Suburb(NMI)

Suburb(NMI)

Postcode(NMI)

Postcode(NMI)

Region

NSW

Installation date

2023-03-23

Bind the current SN to an existing end user

13:05

77

Install New System

Region

SA

Agent

SAPN

NMI

NMI

Installation date

2023-03-03

Bind the current SN to an existing end user account?

No

Yes

User name

User name

Remark(optional)

Fill in the issue

Please enter your installer account and click Install New System to bind the system to your account and set the system.

Enter S/N, check code, license, create time, customer full name, contact number, address, and click the save button. If you are an Australian installer, you will need to fill in the Street (NMI), Suburb (NMI) and Postcode (NMI) fields and add a new Region field, which has six fixed options (NSW, QLD, VIC, SA, TAS, WA). If SA is selected for Region, two more fields are added which are Agent and NMI.

Fields that are not marked "optional" need to be filled in.

Click "Next" to go to the installation steps interface.

13:21

< **Install New System**

1 Product Configuration

System Model

BW-INV-TPH10K

Battery Model

Including WiFi Module? Yes

Installed, skip installation steps

Next

If there is a WiFi module, please choose "Including WiFi Module" as "Yes", the APP will jump to the WiFi configuration page.

13:23

< **Install New System**

Work Mode AC

Energy Storage Inverter PV Capacity(kWp) 5

PV-inverter PV Capacity(kWp) 5

Max.Feed-in(%) 100

Time zone Dateline Standard Time

Meter on the grid side Meter CT

Meter on the PV side Meter CT

Generator

Last Step

Submit

Select Work Mode "DC" "AC" or "Hybrid". Here set "AC" as example.

Set PV-inverter PV capacity.

Set allowable feedin ratio from 0%~100%.

On grid side, if only a CT is installed, please select CT for grid side. If the grid meter is installed, please select Meter for grid side.

On PV side, if only a CT is installed, please select CT for PV side. If the PV meter is installed, please select Meter for PV side.

Click "Submit" after settings complete.

NOTICE

The safety standard must be set correctly

If you select a safety standard which is not valid for your country and purpose, it can cause a disturbance in the energy storage system and lead to problems with the grid operator. When selecting the safety standard, you must always observe the locally applicable standards and directives as well as the properties of the PV system (e.g. PV system size, grid-connection point).

- If you are not sure which safety standard is valid for your country or purpose, contact your grid operator for information on which safety standard is to be configured.

If there is a WiFi module, please choose "Including WiFi Module" as "Yes", the APP will jump to the WiFi configuration page, please refer to additional documentation "APP COMMISSIONING GUIDE".

7.2. Register on cloud

7.2.1. Register as installer account

You can create a new account on our web server for the normal monitoring. In addition, a part of our warranty is based on this connection to our web server. The data produced prior to registration can be synchronized to the web server.

Step1: Please use the following steps: Open the portal: monitor.byte-watt.com.

Step2: Please fill in "Username", "Password" and click "Login" if you have already registered.

If not, please register by filling in the following web form:

In this form, all fields with a red star are compulsory, and you can select the finally users or installation procedures.

***Serial number:** EMS serial number.(please see the nameplate of the inverter)

***Username:** Must be an email address.

***Password:** 5-15 letters / numbers / characters
More details are available in the Online Monitoring Web Sever Installers User Manual, which can be downloaded from Neovolt homepage.

7.2.2. Install new system

Log in to your installer account and choose Storage System Maintenance> "Install new system" to register new system at Neovolt Cloud.

The screenshot shows a web interface titled "Install New System". It contains several input fields: "SN", "Check Code", "License", "Create Time", "Remark", and "username". The "Remark" field has a character count "0/128". There is a green button labeled "Attachment" and a toggle switch for "Bind the current SN to an existing end user account?". A blue "Save" button is located at the bottom right of the form.

Enter the system S/N, check code, license, installation date and click the save button. The red * in front of it is required. Click the "Attachment" button to select the attachment you want to add.

08 POWERING ON AND OFF THE SYSTEM

8.1. Powering on the system

Procedure

- 1) Switch on the battery breaker which is on the left side of the inverter.
- 2) Switch on the PV switch (if there is any) at the lower left of the inverter.
- 3) Switch on the battery breakers of all batteries.
- 4) Shortly press the battery power buttons. For more than one parallel battery installed, please shortly press all power buttons within 10 seconds. (For series batteries, please skip this step)
- 5) Switch on the AC breaker between the grid port of the inverter and the grid.
- 6) Switch on the AC breaker between the backup port of the inverter and the loads.
- 7) Switch on the AC breaker (if there is any) between the PV-inverter and the grid.

8.2. Powering off the system

⚠ WARNING

After the energy storage system is powered off, the remaining electricity and heat may still cause electric shocks and body burns. Therefore, put on protective gloves and operate the product 5 minutes after the power-off.

Procedure


- 1) Switch off the AC breaker between the inverter and the loads.
- 2) Switch off the PV switch (if there is any) at the lower left of the inverter.
- 3) Switch off the PV switch between the PV string and the inverter if there is any.
- 4) Long press the power button of each parallel battery for 6 seconds.
(For series batteries, please skip this step)
- 5) Switch off the battery breakers of the batteries.
- 6) Switch off the battery breaker which is on the left side of the inverter.
- 7) Switch off the AC breaker between the inverter and the grid.

9.1. Checking before power-on


No.	Check Item	Acceptance Criteria
1	Mounting environment	The mounting space is proper, and the mounting environment is clean and tidy, without foreign objects.
2	Battery pack and inverter mounting	The battery pack and inverter are mounted correctly, securely, and reliably.
3	Wi-Fi mounting	The Wi-Fi module is mounted correctly, securely, and reliably.
4	Cable layout	Cables are routed properly as required by the customer.
5	Cable tie	Cable ties are secured evenly and no burr exists.
6	Grounding	The ground cable is connected correctly, securely, and reliably.
7	Switch and breakers status	The PV switch (if there is any) and battery breakers and all the breakers connecting to the product are OFF.
8	Cable connections	The AC cables, PV cables (if there is any), battery power cables, and communication cables are connected correctly, securely, and reliably.
9	Unused power terminals	Unused power ports and communication ports are blocked by watertight caps.

9.2. Mounting the covers of the Inverter


9.2.1. Mounting the top cover




9.2.2. Mounting the side plate (installed on the battery)



9.2.3. Mounting the side plate (wall bracket installation)



9.3. Mounting the Wi-Fi moudle



10 MAINTENANCE AND TROUBLESHOOTING

10.1. Routine maintenance

Normally, the energy storage system need no maintenance or calibration. However, in order to maintain the accuracy of the SOC, it is recommended to perform a full charge calibration for SOC (charging battery until the charging power is 0) on the battery at regular intervals (such as two weeks). Disconnect the system from all power sources before cleaning. Clean the housing, cover and display with a soft cloth. To ensure that the energy storage system can operate properly in the long term, you are advised to perform routine maintenance on it as described in this chapter.

Maintenance checklist

Check Item	Acceptance Criteria	Maintenance Interval
Product cleanliness	The heatsink at the back of the product are free from obstacles or dust.	Once every 6 to 12 months
Product visible damage	The product are not damaged or deformed.	Once every 6 months
Product running status	1. The product operate with no abnormal sound. 2. All parameters of the product are correctly set. Perform this check when the product is running.	Once every 6 months
Electrical connections	1. Cables are securely connected. 2. Cables are intact, and in particular, the cable jackets touching the metallic surface are not scratched. 3. Unused cable glands are blocked by rubber sealing which are secured by pressure caps.	Perform the first maintenance 6 months after the initial commissioning. From then on, perform the maintenance once every 6 to 12 months.

 CAUTION

Risk of burns due to hot heatsink and housing

The heatsink and housing of the inverter can get hot during operation.

- During operation, do not touch any parts other than the cover.
- Wait approx. 30 minutes before cleaning until the heatsink has cooled down.

10.2. Troubleshooting

10.2.1. Inverter error troubleshooting

Error No.	Error description	Troubleshooting
100007	Insulation_fault	1. Check whether PV cable connection is reliable. 2. Check whether PV cable is damaged.
100008	GFCI_fault	Restart system and check whether the fault is existing.
100009	Leakage current test failure	
100025	BAT_OVP	Check whether the actual battery voltage exceeds the battery charging cut-off voltage by more than 20V.
100026	BAT_UVP	Check whether the actual battery voltage is lower than the battery discharge cut-off voltage.
100042	Output_short_circuit	1. Use a multimeter to test the impedance of the off grid output. If it is small, check whether the wiring is correct. 2. Restart system, if error still exists, please call the service center.
100043	Output_overload	1. Check whether the load exceeds the rated power. 2. Restart system, if error still exists, please call the service center.
100043	Grid Load Reverse	1. Check whether cables are reversed (whether Grid cable is connected to the Backup side). 2. Restart system, if error still exists, please call the service center.
100144	LPE Reverse	1. Check whether the L cable is connected to the Grounding. 2. Restart system, if error still exists, please call the service center.
100160	DCI	Restart system to see if the fault still exists. If still exists, please call the service center.
100161	SW Consistency	Perform the remote upgrading again and ensure that the version of CPU1 and CPU2 upgrade files is the same.
100162	N-N Reverse Lost	1. The system installed in Australia needs to check whether N-N is short-circuited. 2. If not in Australia, set the safety standard correctly. 3. Restart system, if error still exists, please call the service center.

100220	inv_line_short	1. Check whether the load is short-circuited connected. 2. Restart system, if error still exists, please call the service center.
110000	Bat over-voltage alarm	Check that the actual battery voltage is 10V higher than the battery charging cut off voltage.
110001	Bat under-voltage alarm	Check that the actual battery voltage is 10V higher than the battery discharging cut-off voltage.
110002	output_overload_alarm	Check whether the load exceeds 0.95 of the rated power.
110019	Bat Reverse	Check whether battery positive and negative connections are reversed.
110021	Grid Loss	1. Wait for the Grid power return to normal. 2. If Grid is normal, check the connections to the grid terminal. 3. Restart system, if error still exists, please call the service center.
110022	Grid Volt	
110023	Grid Freq	
110024	10min Grid Volt	
110026	PE Loss	1. Check whether the grounding cable is disconnected. 2. Restart system(This warning does not affect system running).
110027	LN Reverse	1. Check whether the Grid L/N cable are reversed connected. 2. Restart system, if error still exists, please call the service center.
110028	Low Temperature	1. Wait for the temperature to return to normal (above -20 °C). 2. If temperature is normal, restart system, if error still exists, please call the service center.
110029	GFCI	1. Check whether there is leakage current in system cables. 2. If no abnormal connection, but still error frequently, please call the service center.
110033	Island	Normal protection mode, no action is required.

110034	Fan Abnormal	Restart system, if error still exists, please call the service center.
110035	N Loss	1. Check whether the Grid N cable is disconnected. 2. Restart system, if error still exists, please call the service center.
110039	Machine Type	Restart system, if error still exists, please call the service center.
110040	Inv Volt Low	1. Check whether the Backup load power exceeds the inverter rated power. 2. Restart system, if error still exists, please call the service center.
110047	Bus Under	1. Wait for the Grid power restore to normal. 2. Charge the battery and wait until the battery restore.
110051	Reduce PBy Over Freq	Wait for the Grid power restore to normal.
110052	Reduce PBy Over Volt	Wait for the Grid power restore to normal.
110053	Reduce PBy Over Temp	Wait for the inverter temperature returns to normal.
110054	HVRT	Wait for the Grid power restore to normal.
110055	LVRT	Wait for the Grid power restore to normal.
110056	Bat Open	Check the battery circuit breaker and the battery circuit breaker on the inverter are on.
110060	EMS CAN ALARM	Restart system, if error still exists, please call the service center.
110061	EMS SCI ALARM	Restart system, if error still exists, please call the service center.
110074	PV Over Volt	1. Check whether the configured voltage of the PV panel is greater than 580V(Use a multimeter to measure the PV terminal voltage). 2. Restart system, if error still exists, please call the service center.
110082	N-N Reverse Lost	1. The system installed in Australia needs to check whether N-N is short-circuited. 2. If not in Australia, set the safety standard correctly. 3. Restart system, if error still exists, please call the service center.

110083	Bat_Num_Abnormal	Restart system, if error still exists, please call the service center.
--------	------------------	--

10.2.2. Battery protection troubleshooting

LED Indicator	Error Code	Description	Troubleshooting
Yellow LEDs on or Yellow LEDs flash once per second.	1	Temperature difference	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	3	High temperature	Stop discharging and charging until this code is eliminated and wait for the temperature to drop.
	4	Low-temperature discharge	Stop discharging until this code is eliminated and wait for the temperature to rise.
	5	Over-current charge	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	6	Over-current discharge	
	8	Cell overvoltage	
	9	Cell undervoltage	Stop discharging and call the service immediately.
	11	Low-temperature charge	Stop discharging until this code is eliminated and wait for the temperature to rise.

 NOTE	In the case of work mode, if the protection code 9 appears, please press the power button of the battery 5 times within 10 seconds, the BMS will be forced to turn on the MOSFET of discharge so that the inverter can detect the battery open voltage and charge the battery.
---	--

10.2.3. Battery error troubleshooting

LED Indicator	Error Code	Description	Troubleshooting
Yellow LEDs on or Yellow LEDs flash once per second.	Error 01	Hardware error	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	Error 05	Hardware error	
	Error 06	Circuit breaker open	Switch on circuit breaker after powering off the battery.
	Error 08	LMU disconnect(slave)	Reconnect the BMS communication cable.

Yellow LEDs on or Yellow LEDs flash once per second.	Error 09	SN missing	Call for service.
	Error 10	LMU Disconnect(master)	Reconnect the BMS communication cable.
	Error 11	Software version inconsistent	Call for service.
	Error 12	Multi master	Restart all batteries.
	Error 13	MOS over temperature	Power off the battery and power on the battery after 30minutes.
	Error 14	Insulation fault	Restart battery and in case the problem is not resolved, call for service.
	Error 15	Total voltage fault	Restart battery and in case the problem is not resolved, call for service.

11 UNINSTALLATION & RETURN

11.1. Removing the product

Procedure

- Step 1:** Power off the energy storage system by following instructions in Chapter 7.2. Powering Off the System.
- Step 2:** Disconnect all cables from the product, including communication cables, PV power cables, battery power cables, AC cables, and PE cables.
- Step 3:** Remove the WiFi module.
- Step 4:** Remove the product from the wall bracket. Remove the expansion battery from the wall bracket.
- Step 5:** Remove the wall brackets.

NOTE

If uninstalling electrical connection required, the special disassembly tools must be used and should be performed by qualified person.

11.2. Packing the product

If the original packaging is available, put the product inside it and then seal it using adhesive tape. If the original packaging is not available, put the product inside a suitable cardboard box and seal it properly.

11.3. Disposing of the product

- If the product service life expires, dispose of it according to the local disposal rules for electrical equipment and electronic component waste.
- Dispose of the packaging and replaced parts according to the rules at the installation site where the device is installed.
- Do not dispose the product with normal domestic waste.





12.1. Datasheet of inverter

Item	BW-INV-SPH3.6K	BW-INV-SPH5K	BW-INV-SPB5K	BW-INV-SPH6K	BW-INV-SPH8K
Input DC (PV side)					
Recommended max. PV power	7360W	10000W	N/A	10000W	10000W
Max. PV input voltage	580 V		N/A	580 V	
Rated voltage	360 V		N/A	360 V	
Start-up voltage	90 V		N/A	90 V	
MPPT voltage range	100 ~ 550 V		N/A	100 ~ 550 V	
Max. Input Current Per MPPT	15 A / 15 A		N/A	15 A / 15 A	
Max. Short Circuit Current Per MPPT	18.75 A / 18.75 A		N/A	22.5 A / 22.5 A	
MPPT Number	2		N/A	2	
Max Input Strings Number Per MPPT	1		N/A	1	
Battery					
Battery Type	LFP (LiFePO ₄)				
Battery Voltage Range	80 ~ 450 V			80 ~ 467.2 V	
Maximum Charging Power	3.6 kW	5 kW	5 kW	6 kW	8 kW
Maximum Charge/discharge current	60 A / 60 A				
Communication	CAN				

Output AC (Back-up)					
Rated output power	3.6 kW	5 kW	5 kW	6 kW	8 kW
Max Apparent Output Power	7.36 kVA	10 kVA	10 kVA	11.5 kVA	11.5 kVA
Back-up switch time	<20 ms				
Rated output voltage	L/N/PE, 230V				
Rated Frequency	50/60 Hz				
Rated output current	15.7 A	21.7 A	21.7 A	26.0 A	34.7 A
Max output current	16.4 A	22.7 A	22.7 A	27.3 A	50.0A
THDv(@linear load)	< 3%				
Input AC (Grid side)					
Max. input Power	7.36 kW	10 kW	10 kW	11.5 kW	11.5 kW
Max. input current	32.0 A	43.5 A	43.5 A	50.0 A	50.0 A
Output AC(Grid side)					
Rated output power	3.6 kW	5 kW	5 kW	6 kW	8 kW
Max. Apparent Output Power	3.6 kVA	5 kVA	5 kVA	6 kVA	8 kVA
Operation Phase	Single phase				
Rated Grid Voltage	L/N/PE, 230V				
Grid Voltage Range	170 ~ 270 V				
Rated Grid Frequency	50 / 60 Hz				
Rating Grid Output Current	15.7 A	21.7 A	21.7 A	26 A	34.7 A
Max Grid output current	15.7 A	21.7 A	21.7 A	26 A	34.7 A
Power Factor	0.8 Leading - 0.8 Lagging				
THDI	< 3%				

Protection Class	I				
Overvoltage Category	III				
Efficiency					
Max Efficiency	>97 %				
EU Efficiency	>96.2 %				
Protection					
Anti-Islanding Protection	Integrated				
Insulation Resistor Detection	Integrated				
Residual Current Monitoring Unit	Integrated				
Output Over Current Protection	Integrated				
Output Short Protection	Integrated				
Output Overvoltage Protection	Integrated				
DC Reverse Polarity Protection	Integrated				
PV Overvoltage Protection	Integrated				
PV Switch	Integrated				
Battery Breaker	Integrated				
General data					
Dimensions (W*H*D)	590*405*205 mm				
Weight	19.5 kg	19.5 kg	17.5 kg	20.5 kg	21 kg
Topology	Transformerless				
Operation Temperature Range	-25 ~ +60 °C (derating above 45 °C)				

Ingress Protection	IP65	
Noise Emission	<30 dB	<45 dB
Cooling Concept	Natural convection	Fan cooling
Max. Operation Altitude	3000 m	
Grid Connection Standard	G98/G99, VDE-AR-N 4105, EN 50549-1,VDE 0126, RD 1699, CEI 0-21, C10/11, NRS 097-2-1,MEA, PEA, AS/NZS 4777.2	
Safety/ EMC Standard	IEC62109-1/-2 IEC/EN61000-6-1/2/3/4	
Features		
PV Connection	Vaconn D4 connectors	
Grid Connection	Plug in connector	
Back-up Connection	Plug in connector	
BAT Connection	Screw terminal	
Communication	LAN, Wi-Fi(optional)	
Warranty	5 years standard(10 years optional)	

12.2. Datasheet of battery

Model	BW-BAT-9.6P	BW-BAT-4.8S
Battery type	LFP (LiFePO4)	LFP (LiFePO4)
Weight	85.7 kg	53 kg
Dimension (W*D*H)	590 * 730 * 206 mm	590 * 430 * 206mm
Ingress protection	IP65	IP65
Energy capacity	9.6 kWh	4.8 kWh
Usable capacity	9.1 kWh	4.56 kWh

DoD	95%	95%
Nominal voltage	96 V	96 V
Operating voltage range	90 ~ 108 V	90 ~ 108 V
Max. Charging / discharging current *	50 A/50 A	50 A/50 A
Operating temperature range	Charge: 0<T<50℃ / Discharge: -10<T<50℃	
Monitoring parameters	System voltage, current, cell voltage, cell temperature, PCBA temperature	
BMS communication	CAN	
System		
Safety	IEC62619/IEC62040	
Warranty	5 Years product warranty, 10 Years performance warranty	
Transportation	UN38.3	


* Max. charge/discharge current derating will occur related to temperature and SOC.

Please see the following wiring diagram of the system principle, divided into European versions.

412-90017-01



Single-phase System Wiring Diagram with CHINT Electricity Meter DTSU666 (With 3CT or 6CT)(EU)




Page 3

Single-phase System Wiring Diagram with CT

412-90017-01


NOTICE
(Only for Australia and New Zealand
installation site)



Page 4

Single-phase System Wiring Diagram with CHINT Electricity Meter DTSU666 (Without CT)


NOTICE
(Only for Australia and New Zealand installation site)



Page 5


Single-phase System Wiring Diagram with CHINT Electricity Meter DTSU666 (With 3CT or 6CT)

NOTICE
(Only for Australia and New Zealand installation site)




Page 6

Diesel engine pure off-grid system wiring diagram



Pure off-grid system wiring diagram



Appendix 2: Regional application standard

Please check with your local grid company and choose the correspond Regional Application Standard, the power quality modes Volt-var and Volt-Watt will be running automatically. (Only for regions with AS/NZS 4777.2 safety regulations).

Regional Application Standard	Electric Company
Australia A	N/A
Australia B	N/A
Australia C	N/A
New Zealand	N/A
Vector	New Zealand Vector

 13 CONTACT US

Name: Bytewatt Technology Co.,Ltd.
Tel: +86 180 1268 7058
Address: No.137, West Shihu Road, Wuzhong District, Suzhou City , Jiangsu Province, P.R.China
Postcode: 215000